

Self-Monitoring System Installation

for Andersen® Windows and Patio Doors with VeriLock® Integrated Security Sensors
or Wireless Open/Closed Sensors

Thank you for choosing Andersen.

For questions call 1-877-288-7707. For more information visit www.nexiahome.com.


Please leave this guide with building owner.

Parts Included

- (1) Instruction Guide
- (1) Andersen™ Translator
- (1) Nexia® Bridge
- (1) Network Cable
- (1) 9V Battery

System Requirements


- High speed internet connection
- Open Ethernet internet connection




Nexia® Bridge



9V Battery



Network Cable



Andersen™ Translator

IMPORTANT

Place Nexia Bridge in an open space for proper communication with other devices.
Do not set on top other electronic devices or in metal enclosures.

Create Your Nexia Account

1. Visit www.mynexia.com
2. Click “**Sign Up**” button.
3. Follow on screen prompts to create your account.
4. You will receive an email to verify and activate your account.
5. Click on link sent in the email and login to your account.

Locate 12 digit MAC ID on yellow sticker on inside battery door of the Nexia Bridge. Record MAC ID.

<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------

Add Devices to Your Account

6. Click boxes next to the Nexia Bridge, translator, and other compatible Nexia devices to enroll to your account. (Additional devices can be enrolled at any time.)
7. Follow on screen prompts to enroll each device and customize your home network.

Instalación del sistema de automonitoreo

para ventanas y puertas de patio Andersen® con sensores de seguridad integrados VeriLock® o sensores inalámbricos abiertos/cerrados


Gracias por elegir Andersen.

Si tiene preguntas, comuníquese al 1-877-288-7707. Para obtener más información, visite www.nexiahome.com.

Deje esta guía con el dueño de la construcción.

Partes incluidas


- (1) Guía de instrucciones
- (1) Traductor Andersen™
- (1) Puente Nexia®
- (1) Cable de red
- (1) Batería de 9V




Puente Nexia®



Batería de 9V



Cable de red



Traductor Andersen™

Requisitos del sistema

- Conexión a Internet de alta velocidad
- Conexión a Internet en minúscula por Ethernet abierta

IMPORTANT

Coloque el Puente Nexia en un espacio abierto para la comunicación adecuada con otros dispositivos. **No lo coloque encima de otros dispositivos electrónicos o en envases de metal.**

Cree su cuenta de Nexia

1. Visite www.mynexia.com
2. Haga clic en el botón **"Inscribirse"**.
3. Siga las indicaciones que aparecen en la pantalla para crear su cuenta.
4. Usted recibirá un correo electrónico para verificar y activar su cuenta.
5. Haga clic en el enlace proporcionado en el correo electrónico e inicie sesión en su cuenta.

Ubique la MAC ID de 12 dígitos en la etiqueta amarilla en la parte interior de la puerta de la batería del Puente Nexia. Registre la MAC ID.

--	--	--	--	--	--	--	--	--	--	--	--

Agregue dispositivos a su cuenta

6. Haga clic en las casillas junto al Puente Nexia, el traductor y otros dispositivos Nexia compatibles para registrar su cuenta. (Puede registrar dispositivos adicionales en cualquier momento).
7. Siga las indicaciones que aparecen en la pantalla para registrar cada uno de los dispositivos y personalizar su red del hogar.