



Parental Controls – Video Transcript

Setting parental locks for the DVR allows you to restrict viewing of recorded programs

Step one: From the main menu, select Parental Controls.

Step two: Enter your four-digit PIN. You can select parental locks from a number of options, including movie ratings, TV ratings, or TV content.

Step three: Follow the on-screen prompts to set the locks of your choice.

Once the program has been recorded, it can be viewed by entering your PIN. If you are still experiencing technical difficulties, please contact the Cable One Technical Care Center at support.cableone.net for more assistance.