



DVR Recording – Video Transcript

How to record live TV for easy OneTouch recording

Press Record on your Cable One remote while you are watching TV or navigating through the programming guide.

Recording from the I Guide:

Step one: Press the Guide button to access the I Guide.

Step two: Highlight the program you want to record from any listing screen.

Step three: Press Record to set up the recording.

Programming your DVR to record a specific time and channel:

Step one: Select DVR from the main menu.

Step two: Select Set a Recording.

Step three: Select the start and end times and the day you wish to record, and confirm your settings. A manual recording screen will appear, allowing you to choose the channel you want to record and Create a new recording screen will appear.

Step four: Select Record to confirm your settings, or select View Recording Setting.

Programming your DVR to record multiple episodes of a TV series:

Step one: Press the Menu button on the remote to access the Quick Menu.

Step two: Select the DVR icon.

Step three: Select Future Recordings.

Step four: Press Select and toggle to Future Recording Settings.

Step five: Choose between First Round Only or All Episodes.

Step six: Specify how many recordings to save and how long to save the recording. You can choose between I Delete and Space Is Needed.

Don't miss the end of the game. Add record minutes so you don't miss the full event

Step one: Press the Menu button on the remote to access the Quick Menu.

Step two: Select the DVR icon.

Step three: Select Future Recordings.

Step four: Press Select and toggle to Future Recording Settings.

Step five: Select Start Recording and Stop Recording to add minutes to the start and end times of your specific recorded program.

If you are still experiencing technical difficulties, please contact the Cable One Technical Care Center at support.cableone.net for more assistance.