

This supplement covers installation of the half and full screen for Wood pocket windows. Please follow all of the steps in the full set of installation instructions and install the screen after all other instructions are complete.


NEEDED TOOLS

- Pencil
- Hammer
- Screwdrivers
- Drill with 1/4" bit

FULL SCREEN



1. On the exterior, position one hanger on the window frame next to the stop at the top of the window as shown. Nail into place. Repeat for the opposite side.

2. Slide the screen into the hangers (the hangers can be rotated out slightly to help get the screen frame in). Move the bottom of the screen in toward the window frame until it is against the stop.




3. Hold the screen in place and extend the loops out toward the interior of the window frame and mark the location for the ball heads.

4. Fasten the ball heads into place with the screw and check for proper operation.




HALF SCREEN

1. Position the screen on the exterior side lower half of the window frame with the plunger handles to the interior and the weatherstrip on top. Mark where each plunger pin contacts the frame.



2. Remove the screen and drill a 1/4" diameter x 1/4" deep hole in the center of the exterior stop area at each mark.

3. Install screen by pulling the plunger pins toward the center of the screen, pull the screen in until it hits the stop, then release the pins when they will fit into the previously drilled holes.



4. When painting or finishing, make sure the plunger holes are not filled with paint that will restrict operation.

The information contained herein is provided solely for informational and/or educational purposes. JELD-WEN disclaims any and all liability associated with the use and/or provision of this information. Any reliance upon the information or advice is at the risk of the party so relying. The information contained herein may be changed from time to time without notification.


Este complemento cubre la instalación de la malla completa y de la media malla para ventanas empotrables de madera. Por favor siga todos los pasos del conjunto completo de las instrucciones de instalación e instale la malla cuando ya haya terminado esas instrucciones.

HERRAMIENTAS NECESARIAS:

- Lápiz
- Martillo
- Desarmador
- Taladro con broca de 1/4"

MALLA COMPLETA


1. Por el exterior, coloque un soporte colgante en el marco de la ventana, cerca del tope que se encuentra en la parte superior de la ventana, como se muestra. Fíjelo en su sitio con clavos. Haga lo mismo en el lado opuesto.



2. Deslice la malla para insertarla en los soportes colgantes (los soportes se pueden rotar ligeramente para permitir que el marco de la malla se inserte). Presione la parte inferior de la malla hacia dentro, hacia el marco de la ventana, hasta que quede contra el tope.


3. Sostenga la malla en su sitio y estire los aros hacia el interior del marco de la ventana; marque la posición para las cabezas de bola.

4. Fije las cabezas de bola en su sitio con el tornillo y revise que funcionen bien.



MEDIA MALLA


1. Coloque la malla en la mitad inferior del lado exterior del marco de la ventana, con las manijas de los pernos hacia el interior y el burlete en la parte superior. Marque el punto donde el vástago de cada perno hace contacto con el marco.



2. Retire la malla y taladre un orificio de 1/4" de diámetro x 1/4" de profundidad en la parte exterior, centrado en el lugar que corresponde al tope, en cada marca.

3. Para instalar la malla, jale los vástagos de los pernos hacia el centro de la malla; empuje la malla para meterla hasta que llegue al tope, y luego suelte los vástagos cuando embonen en los orificios previamente taladrados.

4. Cuando pinte o dé acabado cuide de no llenar con pintura los orificios para los pernos, ya que estorbaría el funcionamiento.



La información que se muestra aquí se proporciona únicamente para fines de información o enseñanza. JELD-WEN renuncia a toda responsabilidad asociada al uso de estas instrucciones o a cómo se disponga de ellas. La confianza que se ponga en la información o los consejos es a riesgo de la parte que confía en ellos. La información que se incluye aquí puede cambiar de vez en cuando sin previa notificación.